

INSTALLATION INSTRUCTIONS GRILL GUARD PA RT# 3058/3058-2 05-07 FORD ESCAPE

PRAT LIST:

NO.	N AM E	Q TY	RE MA RK S	N 0.	NA ME	QT Y	R EM AR KS
1	G RI LL E GU AR D	1		8	CO NN EC TI NG PLA TE	2	
2	H EX B OL T	2	M 10 *2 5	9	HE X BOLT	4	M1 2*30
3	F LA T WA SH ER	4	ф10	10	FLAT WASHER	16	Ф 12
4	NY LO N HE X NU T	2	M1 0	11	N YLON LOCK NUT	8	M1 2
5	H EX B OL T	2	M 8*25	12	HEX BOLT	4	M12* 40
6	F LA T WA SH ER	2	ф 8	13	SU PORTIN G PLA TE	2	
7	H EX N UT	2	M8	14	M OU NT IN G BR AC KE T	2	

STEP 1. P LEASE PROT ECT YOUR P RODUC T FROM BEING SCRATCHE D DUR ING THE PROC ESS OF INSTALLING THE GRILLE GUARD).

STEP 2. FIRST, TAKE OFF THE HEX BOLT ON THE VEHICLE.

STEP 3. BE AT TENTI ON TO DIST INGUI SH LEFT AND RIGHT MOUNTS, THEN

INSTALATE THEM (DO NOT SCREW THE BOLTS TIGHTLY), AFTER THAT COMES

TO THE GRILLE GUARD. PUT IT IN PLACE. IN THE END, SCREW ALL THE BOLTS TIGHTLY.

