

INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Chevrolet	Equinox with tow package
GMC	Terrain with tow package

WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S3 - Behind driver side rear access panel

CUSTOM WIRING CONNECTOR



NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

3/16" allen wrench

⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Open the vehicle trunk. Remove all trunk floor coverings (A). Remove the two cargo fasteners on the driver side. Remove the rear scuff panel by pulling out on the bottom and then up. Take care not to damage the alignment tabs on the back. (B).

Step 2

On the driver side only, partially remove the lower trim panel to locate the vehicle taillight wiring connectors. Carefully pull outwards on the lower trim panel (C).

Step 3

Mounted on the bottom rear side-panel, locate the 4-pin vehicle taillight wiring connectors. The connectors will be similar to the one on the custom wiring connector.

Step 4

Insert the custom wiring connector end into the 4-pin vehicle connector. Make sure the connectors are fully inserted with locking tabs in place (D).

Step 5

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

Step 6

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

